# Driver Update 2 Guide for Solaris 2.6 (Intel Platform Edition)

Sun Microsystems, Inc.
901 San Antonio Road
Palo Alto, CA 94303
U.S.A.

Part No: 805-2804-02
January 1998

Copyright 1997 Sun Microsystems, Inc. 901 San Antonio Road, Palo Alto, California 94303-4900 U.S.A. All rights reserved.

This product or document is protected by copyright and distributed under licenses restricting its use, copying, distribution, and decompilation. No part of this product or document may be reproduced in any form by any means without prior written authorization of Sun and its licensors, if any. Third-party software, including font technology, is copyrighted and licensed from Sun suppliers.

Parts of the product may be derived from Berkeley BSD systems, licensed from the University of California. UNIX is a registered trademark in the U.S. and other countries, exclusively licensed through X/Open Company, Ltd.

Sun, Sun Microsystems, the Sun logo, SunSoft, SunDocs, SunExpress, Solaris, and NFS are trademarks, registered trademarks, or service marks of Sun Microsystems, Inc. in the U.S. and other countries.

The OPEN LOOK and Sun™ Graphical User Interface was developed by Sun Microsystems, Inc. for its users and licensees. Sun acknowledges the pioneering efforts of Xerox in researching and developing the concept of visual or graphical user interfaces for the computer industry. Sun holds a non-exclusive license from Xerox to the Xerox Graphical User Interface, which license also covers Sun's licensees who implement OPEN LOOK GUIs and otherwise comply with Sun's written license agreements.

**RESTRICTED RIGHTS:** Use, duplication, or disclosure by the U.S. Government is subject to restrictions of FAR 52.227–14(g)(2)(6/87) and FAR 52.227–19(6/87), or DFAR 252.227–7015(b)(6/95) and DFAR 227.7202–3(a).

DOCUMENTATION IS PROVIDED "AS IS" AND ALL EXPRESS OR IMPLIED CONDITIONS, REPRESENTATIONS AND WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT, ARE DISCLAIMED, EXCEPT TO THE EXTENT THAT SUCH DISCLAIMERS ARE HELD TO BE LEGALLY INVALID.

---

Copyright 1997 Sun Microsystems, Inc. 901 San Antonio Road, Palo Alto, Californie 94303-4900 Etats-Unis. Tous droits réservés.

Ce produit ou document est protégé par un copyright et distribué avec des licences qui en restreignent l'utilisation, la copie, la distribution, et la décompilation. Aucune partie de ce produit ou document ne peut être reproduite sous aucune forme, par quelque moyen que ce soit, sans l'autorisation préalable et écrite de Sun et de ses bailleurs de licence, s'il y en a. Le logiciel détenu par des tiers, et qui comprend la technologie relative aux polices de caractères, est protégé par un copyright et licencié par des fournisseurs de Sun.

Des parties de ce produit pourront être dérivées du système Berkeley BSD licenciés par l'Université de Californie. UNIX est une marque déposée aux Etats-Unis et dans d'autres pays et licenciée exclusivement par X/Open Company, Ltd.

Sun, Sun Microsystems, le logo Sun, SunSoft, SunDocs, SunExpress, Solaris, et NFS sont des marques de fabrique ou des marques déposées, ou marques de service, de Sun Microsystems, Inc. aux Etats-Unis et dans d'autres pays.

L'interface d'utilisation graphique OPEN LOOK et Sun™ a été développée par Sun Microsystems, Inc. pour ses utilisateurs et licenciés. Sun reconnaît les efforts de pionniers de Xerox pour la recherche et le développement du concept des interfaces d'utilisation visuelle ou graphique pour l'industrie de l'informatique. Sun détient une licence non exclusive de Xerox sur l'interface d'utilisation graphique Xerox, cette licence couvrant également les licenciés de Sun qui mettent en place l'interface d'utilisation graphique OPEN LOOK et qui en outre se conforment aux licences écrites de Sun.

CETTE PUBLICATION EST FOURNIE "EN L'ETAT" ET AUCUNE GARANTIE, EXPRESSE OU IMPLICITE, N'EST ACCORDEE, Y COMPRIS DES GARANTIES CONCERNANT LA VALEUR MARCHANDE, L'APTITUDE DE LA PUBLICATION A REPONDRE A UNE UTILISATION PARTICULIERE, OU LE FAIT QU'ELLE NE SOIT PAS CONTREFAISANTE DE PRODUIT DE TIERS. CE DENI DE GARANTIE NE S'APPLIQUERAIT PAS, DANS LA MESURE OU IL SERAIT TENU JURIDIQUEMENT NUL ET NON AVENU.

# Contents

**Preface v**

**1. Driver Update 2 for Solaris 2.6 (Intel Platform Edition) 1**

New Device Functionality 1

Device Drivers 1

Driver Update Contents 3

Solaris 2.6 Device Configuration Assistant, Version 1.2 Diskette 4

Driver Update Diskettes 4

Driver Update 2 Release Notes 6

Installing Solaris Using the Driver Update 7

Adding New or Updated Drivers to an Existing Solaris System 10

100-Mbps Ethernet Performance Problem on Some Intel Motherboard Chipsets 12

# Preface

This document provides information about x86 hardware devices that are now supported in the Solaris™ 2.6 computing environment. Typically, as new or updated drivers become available, they are bundled with a release in a separate Driver Update. You can use a Driver Update to install a new system for the first time or to update your installed Solaris 2.6 system with new and updated drivers.

Since Driver Updates are cumulative distributions for a given Solaris release, "New Device Functionality" on page 1 in Chapter 1 describes what's been added or changed since the last Driver Update. You only need to install the current Driver Update to get the support described in this document.

**Note -** The term "x86" refers to the Intel 8086 family of microprocessor chips, including the Pentium, Pentium Pro, and Pentium II processors and compatible microprocessor chips made by AMD and Cyrix. In this document the term "x86" refers to the overall platform architecture, whereas *"Intel Platform Edition"* appears in the product name.

## Before You Read This Book

The importance of configuring your hardware before Solaris installation is discussed in the Configuring Devices module in *Information Library for Solaris 2.6 (Intel Platform Edition)* (part of Solaris 2.6 System Administrator Collection Vol 1 at `http://docs.sun.com`). This document assumes you have fully read and understood that module.

Beginning with Driver Update 2, those devices that require configuration have Device Reference Pages in *Device Reference Manual for Solaris 2.6*

*(Intel Platform Edition)*. Any names of Device Reference Pages ending in "(DU *x*)" supersede those in the Configuring Devices module and contain device configuration information for hardware supported by new or updated drivers.

The installation instructions in this Driver Update supplement the instructions in *Information Library for Solaris 2.6 (Intel Platform Edition)* and *Solaris Advanced Installation Guide* in Solaris 2.6 System Administrator Collection Vol 1.

# Ordering Sun Documents

The SunDocs℠ program provides more than 250 manuals from Sun Microsystems, Inc. If you live in the United States, Canada, Europe, or Japan, you can purchase documentation sets or individual manuals using this program.

For a list of documents and how to order them, see the catalog section of the SunExpress™ Internet site at `http://www.sun.com/sunexpress`.

# Accessing Sun Documentation Online

The `docs.sun.com` Web site enables you to access Sun technical documentation online. You can browse the `docs.sun.com` archive or search for a specific book title or subject. The URL is `http://docs.sun.com`.

# How to Obtain Technical Support

To obtain technical support:

- Contact your Sun Software Support Provider.
- In North America, you can also call 1-800-SUNSOFT and choose option 4.

CHAPTER 1

# Driver Update 2 for Solaris 2.6 (Intel Platform Edition)

Driver Update 2 (DU 2) provides additional driver support for Solaris 2.6 *Intel Platform Edition* and must be used with this release.

## New Device Functionality

### Device Drivers

This table lists device drivers in Driver Update 2 that contain new and updated functionality added since the last Solaris 2.6 *Intel Platform Edition* Driver Update. A new or updated Section 7D man page for each of the drivers that added new device support is installed in the appropriate `man` page directory during installation.

**Note -** Each driver is assigned a version number. Note that a driver produced by a third-party driver developer is assigned the version number used by that third-party developer and may therefore differ from those Sun Microsystems uses.

**TABLE 1–1** New and Updated Drivers in This Driver Update

| | | |
|---|---|---|
| **SCSI Host Bus Adapters** | | |
| `adp` | Version 2.1 | Fixed a bug in SCSI reset processing where this driver would sometimes experience memory corruption or a panic; added the AHA-3940U and AHA-3940UW host bus adapters to the Device Reference Page |
| `cpqncr` | Version 3.0 | Fixed bugs<br>If your system is running an older version of Compaq's ROMPaq firmware, you may also need to upgrade your system with the latest version of ROMPaq firmware after installing this driver to prevent your system from hanging |
| `pcscsi` | Version 2.1 | Fixed bugs, among them one that occurred when the target ID was greater than seven and another that occurred because the code did not check that DMA memory was set up correctly before packets were re-used; also fixed a framework usage correctness bug that did not affect functionality |
| **SCSI Disk Arrays/RAID Controller** | | |
| `mega` | Version 1.04 | New American Megatrends MegaRAID 428 SCSI RAID controller to support the Solaris 2.6 operating environment; eliminated problems that occurred under heavy stress conditions |
| **SCSI Tape Driver** | | |
| `st.conf` | | Added help text that explains how to submit new entries and where to find documentation about creating entries; uncommented entries so you can use these older tape drives without having to modify `st.conf`: Archive Python 28388, Conner CTD 8004H, Compaq DLT models 4000 and 7000, Sony SDT 7000 and SDT 9000, Wangtek 51000 and 52000, Tecmar TS-420, all shipping models of Sun DLT drives up to DLT 700, Quantum DLT 4000 and 7000, Hewlett-Packard SureStore T4 and 1557A DDS3 autoloader (requires third-party control software), WangDAT models 3400DX and 3800, Exabyte EXB-8900 Mammoth and 8705 Eliant, Tandberg TDC 4120 |
| **Ethernet Network Adapters** | | |

**TABLE 1–1** New and Updated Drivers in This Driver Update *(continued)*

| | | |
|---|---|---|
| `cnft` | Version 4.6 | Fixed bugs |
| `dnet` | Version 2.1 | Fixed bugs (in the media detection code) and added support for both Digital NIC 21142/21143 chips and media for T4 media |
| **Serial Ports Driver** | | |
| `asy` | Version 2.1 | Fixed bugs |

This table lists the MP kernel modules that contain new or changed functionality not included in previous Drivers Updates.

**TABLE 1–2** New and Updated MP Kernel Modules

| | | |
|---|---|---|
| `pcplusmp` | Version 2.1 | Fixed a bug that caused some Compaq MultiProcessor Specification v1.4 Compliant systems to hang (the ProLiant and Professional Workstation Series equipped with or without the Compaq Smart-2/P array controllers, for example)<br>If your system is running an older version of Compaq's ROMPaq firmware, you may also need to upgrade your system with the latest version of ROMPaq firmware after installing this driver to prevent your system from hanging |

# Driver Update Contents

Driver Update 2 for Solaris 2.6 *Intel Platform Edition* contains the following diskettes:

- Solaris 2.6 Device Configuration Assistant, Version 1.2 Diskette
- Solaris 2.6 Driver Update 2 Diskette 1
- Solaris 2.6 Driver Update 2 Diskette 2
- Solaris 2.6 Driver Update 2 Diskette 3

These diskettes are to be used with a Solaris 2.6 CD or net install image.

# Solaris 2.6 Device Configuration Assistant, Version 1.2 Diskette

If you are installing Solaris 2.6 *Intel Platform Edition* and you want to install the drivers in Driver Update 2, you must use Solaris 2.6 Device Configuration Assistant, Version 1.2 Diskette instead of the Solaris 2.6 Device Configuration Assistant diskette you received with Solaris 2.6 *Intel Platform Edition*.

You can download Solaris 2.6 Device Configuration Assistant, Version 1.2 Diskette from `http://access1.sun.com/drivers`.

This diskette contains scripts and configuration files that enable you to boot and install your system using one of the newly supported devices.

# Driver Update Diskettes

Solaris 2.6 Driver Update 2 diskettes are used when you use the new Solaris 2.6 Device Configuration Assistant, Version 1.2 Diskette to install the Solaris 2.6 operating environment. Alternatively, you can use the Driver Update diskettes without the Device Configuration Assistant diskette to add new and updated drivers to an existing x86 based system running the Solaris 2.6 release.

The Driver Update diskettes contain the drivers listed below. A new or updated Section 7D man page for each of the drivers that added new device support will also be installed in the appropriate `man` page directory during installation.

**TABLE 1–3** Device Drivers in This Driver Update

| | | |
|---|---|---|
| **SCSI Host Bus Adapters** | | |
| `adp` | Version 2.1 | Fixed a bug in SCSI reset processing where this driver would sometimes experience memory corruption or a panic; added the AHA-3940U and AHA-3940UW host bus adapters to the Device Reference Page |
| `aha` | Version 2.1 | Fixed bugs, among them one that prevented users from net installing using an AHA-1540 MCA card, one that caused a delay when scanning devices, and three that relate to stress tests; added support for inserting two AHA cards in the same PC at the same time |
| `cpqncr` | Version 3.0 | Fixed bugs |

**TABLE 1–3** Device Drivers in This Driver Update *(continued)*

| | | |
|---|---|---|
| `eha` | Version 2.1 | Removed some non-conforming code; functionality remains unchanged |
| `mcis` | Version 2.1 | Cleaned up the code; functionality remains unchanged |
| `ncrs` | Version 2.1 | Added support for new version of the BIOS that comes with the Symbios Logic (also NCR) controllers that are already supported by this driver |
| `pcscsi` | Version 2.1 | Fixed bugs, among them one that occurred when the target ID was greater than seven and another that occurred because the code did not check that DMA memory was set up correctly before packets were re-used; also fixed a framework usage correctness bug that did not affect functionality |
| **SCSI Disk Arrays/RAID Controller** | | |
| `mega` | Version 1.04 | New American Megatrends MegaRAID 428 SCSI RAID controller to support the Solaris 2.6 operating environment; eliminated problems that occurred under heavy stress conditions |
| **SCSI Tape Driver** | | |
| `st.conf` | | Added help text that explains how to submit new entries and where to find documentation about creating entries; uncommented entries so you can use these older tape drives without having to modify `st.conf`: Archive Python 28388, Conner CTD 8004H, Compaq DLT models 4000 and 7000, Sony SDT 7000 and SDT 9000, Wangtek 51000 and 52000, Tecmar TS-420, all shipping models of Sun DLT drives up to DLT 700, Quantum DLT 4000 and 7000, Hewlett-Packard SureStore T4 and 1557A DDS3 autoloader (requires third-party control software), WangDAT models 3400DX and 3800, Exabyte EXB-8900 Mammoth and 8705 Eliant, Tandberg TDC 4120 |
| **Ethernet Network Drivers** | | |
| `cnft` | Version 4.5, Version 4.6 | Fixed bugs |

**TABLE 1–3** Device Drivers in This Driver Update *(continued)*

| | | |
|---|---|---|
| `dnet` | Version 2.1 | Fixed bugs (in the media detection code) and added support for both Digital NIC 21142/21143 chips and media for T4 media |
| `pcn` | Version 2.1 | Fixed bugs (both realmode and protect-mode); added support for AMD PCnet-PCI II and PCnet-Fast cards and for Cabletron E-2210 cards |
| **Token Ring Network Adapter** | | |
| `mtok` | Version 3.00.02 | New Madge Smart 16/4 adapter |
| **PC Card (PCMCIA) Hardware** | | |
| `pcata` | Version 2.1 | Fixed a bug so tools like `format` won't try to access the Viper 8260pA or SanDisk Flash PC Card if it isn't inserted in the socket |
| **Serial Ports Driver** | | |
| `asy` | Version 2.1 | Fixed bugs |

# Driver Update 2 Release Notes

For a complete list of the known problems that are fixed in this Driver Update, see the `README` files that get installed in the patch directories `/var/sadm/patch/`*patch-number*.

- Third-party drivers are provided for the convenience of Solaris customers and are tested to ensure that they meet acceptable standards of operability. SunSoft cannot be responsible for their inclusion in a given release or the timeliness of their availability.
- It is important that you configure your hardware according to the manufacturer's guidelines so, for example, there are no resource conflicts in IRQs or I/O address ranges. Configuring your hardware is discussed further in the Configuring Devices module in *Information Library for Solaris 2.6 (Intel Platform Edition)*.
- The Device Reference Pages specify the supported connector type where appropriate. All network devices are assumed to work at 10 Mbps only, unless otherwise specified in the Device Reference Pages in *Device*

*Reference Manual for Solaris 2.6 (Intel Platform Edition)*. See the beginning of Chapter 1 in that manual for network connectors and the media they support.

- Due to conflicts, the IBM Micro Channel SCSI-2 Fast/Wide Adapter/A should not be installed until the Solaris Micro Channel `mcis` driver is disabled.
- To prevent conflicts with the `tr` driver, the `mtok` driver is disabled by default, and special steps must be taken to enable it. See the "Madge Smart 16/4 Token Ring (DU 1)" Device Reference Page.

# Installing Solaris Using the Driver Update

The procedure to install the Solaris operating environment using a Driver Update is changed with the Solaris 2.6 release. Solaris 2.6 Device Configuration Assistant, Version 1.2 Diskette includes a Configuration Assistant program that finds and configures devices for you. Use this diskette to boot the Solaris 2.6 operating environment and Driver Update diskettes to install and update device drivers.

Follow these steps:

1. **Insert Solaris 2.6 Device Configuration Assistant, Version 1.2 Diskette into your machine's diskette drive (Version 1.2 replaces the Version 1.1 diskette and the diskette provided with Solaris 2.6 *Intel Platform Edition*).**
2. **Turn on your machine.**
3. **When the Solaris Device Configuration Assistant screen is displayed, press F4_Driver Update.**

   The message "Enumerating buses ..." is displayed. The Install Driver Update screen is then displayed.
4. **Remove Solaris 2.6 Device Configuration Assistant, Version 1.2 Diskette from the diskette drive and insert Solaris 2.6 Driver Update 2 Diskette 1.**

---

**Note -** Do not insert a Solaris 2.6 Video Driver Update diskette in the diskette drive at this point. You are prompted to do this later.

---

5. **Press F2_Continue.**

   The Select Solaris System Version screen is displayed.
6. **Select Solaris OS 2.6 and press F2_Continue.**

The Loading Driver Update Software screen is displayed, along with a progress bar that shows the percentage of drivers that have been extracted from the diskette. Drivers are read into memory and survive long enough for the system to successfully boot to its installation program. When all the new drivers on the diskette have been processed, the Continue Driver Update Installation screen is displayed.

7. **Remove the Solaris 2.6 Driver Update 2 diskette from the diskette drive and insert the next Solaris 2.6 Driver Update 2 diskette.**

8. **Press F2_Continue.**

   The Loading Driver Update Software screen is displayed, along with a progress bar that shows the percentage of drivers that have been extracted from the diskette. Drivers are read into memory and survive long enough for the system to successfully boot to its installation program. When all the new drivers on the diskette have been processed, the Continue Driver Update Installation screen is displayed.

9. **Repeat** Step 7 on page 8 **through** Step 8 on page 8 **until all Solaris 2.6 Driver Update 2 diskettes are installed.**

10. **When all the drivers are processed, remove the Solaris 2.6 Driver Update 2 diskette from the diskette drive and reinsert Solaris 2.6 Device Configuration Assistant, Version 1.2 Diskette.**

    *Important:* Do *not* remove Solaris 2.6 Device Configuration Assistant, Version 1.2 Diskette from the diskette drive until you see the following message displayed in a dialog box:

```
If you want to bypass the device configuration and boot screens when
the system reboots, eject the Device Configuration Assistant/Boot
diskette now
```

11. **Press F2_Continue.**

    The Solaris Device Configuration Assistant screen is displayed.

12. **Press F2_Continue.**

    The following message is displayed:

```
Enumerating buses ...
```

    The Scanning Devices screen is then displayed. System devices are scanned. When scanning is complete, the Identified Devices screen is displayed.

13. **Press F2_Continue.**

The message "Loading driver `com.bef` ..." is displayed followed by messages about the drivers that are required to boot your system. After a few seconds, the Boot Solaris screen is displayed.

14. **At the Boot Solaris screen, select the device controller attached to the device that contains your install medium.**

15. **Press F2_Continue.**

    Drivers for the device controller you selected are displayed. Your system boots to run the install program. The install program starts and your machine begins booting the complete Solaris 2.6 operating environment. Then, after some time, the following messages are displayed:

```
Installing unbundled device driver support
Extracting driver list from tree..
distribution-diskette-name driver-name...

Please insert the Driver Update diskette labeled distribution-diskette-name
Press <ENTER> when ready.
```

16. **Remove Solaris 2.6 Device Configuration Assistant, Version 1.2 Diskette and reinsert Solaris 2.6 Driver Update 2 Diskette 1 into the diskette drive.**

17. **Press Enter.**

    Patches that contain the new drivers are installed from the diskette onto your machine. Messages about the patches being installed are displayed.

    - If drivers on other Solaris 2.6 Driver Update 2 diskettes are required for your machine, this prompt is displayed:

```
Please insert the Driver Update diskette labeled distribution-diskette-name
Press <ENTER> when ready.
```

    - Otherwise, this prompt is displayed:

```
If you have additional Update diskettes to install
(such as video), please insert diskette now.
Additional Update diskettes to install? (y/n) [y]
```

18. **If drivers on other Solaris 2.6 Driver Update 2 diskettes are required, remove the Solaris 2.6 Driver Update 2 diskette from the diskette drive, insert the next Solaris 2.6 Driver Update 2 diskette you are prompted to insert, press Enter, and repeat until all drivers you need are installed.**

    **If you want to install video drivers, remove the Solaris 2.6 Driver Update 2 Diskette 1 from the diskette drive, insert a Solaris 2.6 Video**

**Driver Update diskette, type `y` for yes or press Enter, and then follow the directions displayed on your screen.**

**If you don't want to install video drivers, type `n` for no.**

---

**Note -** *Video Driver Update 2 Guide for Solaris 2.6 (Intel Platform Edition)* contains additional information about video drivers.

---

19. **Press Enter.**

    When installation is complete, the message "Installation complete" is displayed.

20. **Remove the diskette from the diskette drive.**

21. **Reboot your machine.**

    When the Solaris operating environment is finished booting and running, the new devices whose drivers you installed are available for use.

---

**Note -** If you install a video device driver, you may need to run `kdmconfig` after your system reboots.

---

# Adding New or Updated Drivers to an Existing Solaris System

---

**Note -** Before adding new or updated drivers, the newly supported hardware devices should be installed and configured according to the instructions in the corresponding Device Reference Page, if any. See *Device Reference Manual for Solaris 2.6 (Intel Platform Edition)*.

---

When the Solaris 2.6 *Intel Platform Edition* software is already installed, the simplest way to add new or updated drivers is to install the Driver Update diskettes as patches on your system.

Follow these steps:

1. **Become root.**

2. **Type `ps -ef | grep vold` to see if the Volume Management software is running on the machine you are updating.**

   For more information about managing diskettes and drives, see *System Administration Guide*.

3. **If Volume Management is running, temporarily stop it:**

```
# /etc/init.d/volmgt stop
```

4. **Insert Solaris 2.6 Driver Update 2 Diskette 1 into the diskette drive.**
5. **Mount Solaris 2.6 Driver Update 2 Diskette 1 at the** `/mnt` **mount point:**

```
# mount -F pcfs /dev/diskette /mnt
```

---

**Note -** You must mount Solaris 2.6 Driver Update 2 Diskette 1 at this point in the file structure to update your system successfully.

---

6. **Execute the install script on the diskette by typing:**

```
# /mnt/DU/sol_26/i86pc/Tools/install.sh -i
```

   The `install.sh` script searches for all new or updated drivers on the diskette. When a new or updated driver is found, the following prompt is displayed:

```
Install patch driver-name? [y]
```

7. **If the driver is the one you want to install, at the prompt, type** `y` **for yes or press Enter. If the driver is not the one you want to install, type** `n` **for no.**

   If you specify yes, the `install.sh` script installs the driver you indicated.

8. **When you're done and the** `install.sh` **script exits, unmount the diskette by typing the following command at the system prompt:**

```
# umount /mnt
```

9. **Remove Solaris 2.6 Driver Update 2 Diskette 1 from the diskette drive.**
10. **Repeat** Step 4 on page 11 **through** Step 9 on page 11 **for each subsequent Driver Update 2 diskette in the set until the driver you want is loaded onto your machine.**
11. **Halt your machine.**
12. **Turn your machine off.**

13. **If you haven't already, add the new hardware.**

14. **Turn your machine on.**

15. **When the autoboot sequence prompt is displayed, quickly press Escape.**

    The autoboot sequence is interrupted. The Solaris Device Configuration Assistant screen is displayed.

16. **Press F2_Continue.**

    The message "Enumerating buses ..." is displayed. The Scanning Devices screen is then displayed. System devices are scanned. When scanning is complete, the Identified Devices screen is displayed.

17. **Press F2_Continue.**

    The message "Loading driver `com.bef` ..." is displayed. The Boot Solaris screen is then displayed.

18. **On the Boot Solaris screen, select the device controller attached to the device that contains your install medium, in this case the main system disk.**

    The `/etc/bootrc` script is displayed.

19. **At the prompt, type `b -r`.**

    Your machine boots. You can now use your new hardware.

# 100-Mbps Ethernet Performance Problem on Some Intel Motherboard Chipsets

Some PCI motherboards contain DMA chipsets that are unable to support 100-Mbps Fast Ethernet. Because of this problem, the Solaris operating environment does not support 100-Mbps PCI network operation on systems containing the slow chipsets. This problem affects PCI cards only. Other buses are not affected.

The following chipsets are known to exhibit this problem:

- 82430LX (Mercury)
- 82450GX (Orion) (A and B steppings only)

The following chipsets do *not* exhibit this problem:

- 82430NX (Neptune)
- 82430FX (Triton)
- 82430HX (Triton II)

- 82440FX (Natoma)
- 82450GX (Orion) (C0 stepping and later)

Some slow PCI motherboard chipsets do not support long data burst DMA transfers and are unable to transfer data from PCI cards to system memory sufficiently fast to sustain 100-Mbps throughput. When systems with these chipsets are connected to a 100-Mbps network, data can arrive at a PCI Ethernet card faster than DMA can transfer it from the card to system memory. When this happens, the card's FIFO begins to fill. If this condition persists long enough, the card's FIFO will overflow, causing loss of incoming network data.

When incoming data is lost, higher-level protocols such as TCP or NFS™ will time out and retransmit the lost data. These protocols ensure that all data is transferred, but performance is lowered. If only a few packets are lost, the performance impact may be small or moderate, but if many packets are lost, a very substantial and severe performance loss can arise.

In some cases, a drop in network FTP performance of two orders of magnitude has been seen when using such chipsets, rendering the network unusable. This case occurs when using 100-Mbps cards containing relatively small FIFOs. The cards are designed to be able to hold only a couple of packets, and they depend on the DMA mechanism to transfer data out of the FIFO in a timely way.

In other cases, cards with larger FIFOs are not as severely impacted by the problem, and under normal conditions perform as well on machines with slow chipsets as they do on speedy ones. However, under sustained 100-Mbps operation, this cannot continue indefinitely.

Because of this problem, the Solaris environment does not support 100-Mbps PCI network operation on systems containing the slow chipsets.

In particular, the PCI cards supported by the `dnet`, `iprb`, and `elx` drivers will not provide good performance on machines with the problem chipsets. If 100-Mbps operation is required on such a machine, it is best to use a non-PCI Ethernet controller. It is also possible that the PCI cards supported by the `ieef` driver, which have larger FIFOs, may function adequately. You must decide whether the performance on a particular machine is adequate for the intended purpose.